



**KARADENİZ MAKİNA®**  
YEDEK PARÇA SAN.TİC.LTD.ŞTİ  
İnşaat Makinaları & Jeneratör

# POWER TROWEL

## OPERATION MANUEL

### KM-P90



For the service and maintenance of your machine, please use your authorized service or user manual. Before starting your machine, take adequate safety precautions in the working area.

# 1. INTRODUCTION

## Application

This walk-behind trowel is design for the floating and finishing of concrete slabs.

## Noise emission:

A-weight sound pressure level at work station: 5678987(dB)

The sound power level: 3333333333

Note: the measurement is according to EN12649:2008

## Vibration emission:

Measured vibration emission value a: 888888

Uncertainty K: 789

Note: the measurement is according to EN ISO 20643:2005

## Warnings for incorrect application and abuse

Take a walk around the trowel. Take notice of ali of major components like the engine, blades, quick adjust control, air cleaner, centrifugal stop switch etc. Check that there is always oil in the engine.

Read ali the safety instructions carefully. Safety instructions will be found throughout this manual and on the trowel. Keep all safety information in good, readable condition. Operators should be well trained on the operation and maintenance of the trowel.

## Structure

The upper part is made up of Power source, Handle, Belt Cover and Guard hook which are fixed by Engine base.

The Engine base is fixed on Gearbox.

The lower part is made up of Gearbox, Spider and Blade.

## Power Transfer

Air-cooled Single cylinder Petrol Engine is amounted as power source and Centrifugal Clutch is fixed on engine output shaft.

The power source is transmitted from the centrifugal clutch on engine output shaft to the Gearbox input shaft via V-belt or pulley drive system. The pulley engages using a centrifugal clutch.

The gearbox is located beneath the engine and transfers power to the rotor or spider assembly.

The **gearbox** controls the rotational speed of the trowel and is equipped with two shafts.

The vertical output shaft of the gearbox connects to a cast hub called the **spider** . The spider has 4 arms that extend outward that are used for attachment of blades or other accessories. Remember as the gearbox output shaft rotates so does the spider assembly.

The blades of the trowel finish the concrete as they are rotated around the surface. Blades are classified as **combination** (8 inches wide) and **finish** (6 inches wide). This trowel comes equipped with four blades per rotor equally spaced in a radial pattern and attached to vertical rotating shaft by means of a **spider assembly**.

## 2. SPECIFICATION

| Model                     | P60             | P70             | P90             | P120            |
|---------------------------|-----------------|-----------------|-----------------|-----------------|
| <b>Dimensions</b>         |                 |                 |                 |                 |
| Overall Length      mm    | 1200            | 1450            | 1610            | 2100            |
| Overel Width      mm      | 600             | 710             | 1010            | 1200            |
| Overall Height      mm    | 600             | 510             | 810             | 1000            |
| Net Weight      kg        | 55              | 65              | 80              | 110             |
| Operation Weight      kg  | 60              | 70              | 85              | 115             |
| <b>Performance</b>        |                 |                 |                 |                 |
| Number of Blades          | 4               | 4               | 4               | 4               |
| Blade Tip size      m/s   | 6,5             | 6,5             | 6,5             | 6,5             |
| Ring Width                | 610             | 710             | 910             | 1200            |
| <b>Power Source</b>       |                 |                 |                 |                 |
| Manufacturer              | HONDA           | HONDA           | HONDA           | HONDA           |
| Model                     | GX160           | GX160           | GX200           | GX270           |
| Maz .Output               | 5,5 PS          | 5,5 PS          | 6,5 PS          | 9 PS            |
| Fuel Tank Capacity      L | 3,6             | 3,6             | 3,6             | 3,6             |
| Starting System           | Recoil Starting | Recoil Starting | Recoil Starting | Recoil Starting |
| Set R.P.M      rpm        | 3600            | 3600            | 3600            | 3600            |

### 3. FOR SAFETY OPERATION

#### Foreword:

it is important to read this manual carefully so that you will fully understand the operational characteristics and performance of the plate compactor. Proper maintenance procedures will insure long life and top performance of the unit.

#### Safety:

This section outlines basic safety procedures that apply to the operation, maintenance and adjustment of the CIMAR power trowel. This unit is designed as a powerful, productive machine that should be operated with respect and caution.

Misuse or carelessness can result in serious injury or property damage, or both. Safety precautions must be observed at all times.

- This safety alert symbol identifies important safety messages throughout this manual and on the machine.

When you see the symbol, carefully read the message that follows. Your safety is at stake!

#### Operator Qualifications:

Before operating this equipment, an individual should read this manual. Whenever possible, he should be shown how to operate the unit by an experienced operator. Inexperience is hazardous in operating any machine or attachment. Trial and error is not the way to become familiar with a piece of equipment. This is expensive, cuts equipment life and can create machine downtime. Inexperience can cause injury or death. The machine should not be left unattended when operating.

#### General Safety:

##### **WARNING**

- + Refrain from working in such cases as below:
- + When not feeling well due to fatigue or disease.
- + When taking medicine.
- + Under the influence of alcohol.



##### **CAUTION**

- + Read the instruction manual carefully and operate the machine properly to work safely.
- + With respect to engine, read the separate engine manual.
- + Understand the mechanism of the machine sufficiently.
- + Wear protectors (hard hat, safety shoes, ear plugs, etc.) and proper clothing for working safety.
- + Always check the machine for loosened threads or any other abnormality before starting your work.
- + Whenever affixed name plate (such as operating directions and warnings) become difficult to read, replace it with new one.

- + Machine is hazardous for children to tamper with. Pay enough caution for how and where to store it. Particularly in case of the machine equipped with starting motor, remove starting key to store at designated location.
- + Be sure to shutdown engine for servicing. If equipped with starter motor, disconnect battery wiring.
- + Manufacturer does not assume responsibility for any accident arising from modification.

#### Refueling Safety:

##### **WARNING**

- + Before refueling, be sure to shutdown engine and wait for it to cool.
- + Select location where there is no inflammable matter and be careful not to spill fuel. When spilled however, wipe it off thoroughly.
- + Never use fire in the vicinity while refueling. (Definitely no smoking!)
- + Topping up to filler port is dangerous as it tends to spill fuel.

#### Starting Safety:

##### **CAUTION**

- + Before starting and operating your machine, check for safety of personnel or obstacle around.
  - Always pay attention to ground so you can work in stable position.
- + Whenever machine fails to work properly or any abnormality is noticed during work, suspend your work immediately.
- + Do not touch engine body or muffler as they are hot in operation.
- + Be sure to stop engine whenever you leave the machine. Also, do not forget to stop the engine when you move the machine as well.
- + Poisonous fumes. Start and operate only in well ventilated area. Breathing exhaust gases can result in sickness or death.

#### Servicing Safety:

##### **CAUTION**

- + Before lifting, make sure that machine parts (hook and vibration insulator in particular) are not damaged and screws are not loosened or lost.
- + Stop the engine before lifting your machine. Contact with moving parts can cause serious injury.
- + Allow machine and engine to cool before performing service or maintenance. Contact with hot components can cause serious burns.
- + Use wire rope which has sufficient strength.
- + Use one point suspension hook and lift straight upward without giving any shock.
- + Be sure not to allow any person or animal to enter underneath the lifted machine.
- + For safety, try not to lift to unnecessary height.

Engine:

See engine operations manual

SHUTDOWN:

EMERGENCYSHUTDOWN

Move throttle lever to "OFF" position and also turn stop switch to "OFF".

NORMAL SHUTDOWN

Move throttle lever quickly from "ON" to "OFF" and run engine for 3 to 5 minutes at low speed. After engine cools, turn stop switch to "OFF" position. Close fuel shutoff valve.


## 4. PRIOR TO OPERATION

1. Make sure that all dirt, mud, etc., are thoroughly removed from the unit prior to operation. Special effort should be given to the bottom face of the gearbox and those areas adjacent to the cooling air inlet of engine, carburetor, and air cleaner.
2. Check all bolts and screws for tightness and make sure all bolts and screws are securely tightened. Loose bolts and screws may cause damage to the unit.
3. Check the V-belt for tightness. The normal slack should be approximately 10-15mm (1/2") when the belts are forcibly depressed in the middle position between the two sheaves. If there is excess belt play, there could be a decrease in the impact force or erratic vibration, causing machine damage.
4. Check the engine oil level and if the engine oil level is low, it should be refilled. Use the proper motor oil as suggested in the table below. (Fig-1)

### IMPORTANT:

Use the Motor oil SAE

When changing the oil, the old oil can be drained by tipping the unit. The oil will drain easily while it is hot



5. A regular grade gasoline should be used in the engine. When filling the fuel tank, make sure the fuel filter is used.






| Season      | Temperature    | Oil to be used |
|-------------|----------------|----------------|
| Summer      | 25°C or higher | SAE 10W-30     |
| Spring/Fall | 25°C 10°C      | SAE 10W-30/20  |
| Winter      | 0°C or lower   | SAE 10W-10     |

# 5. STARTING-UP

## Gasoline Engine

1. Align fuel cock lever with FLOW position (Fig.3)
2. When cold or somehow starting is difficult, turn choke lever to START position. This is not necessary when engine is warm. (Fig.4)
3. Turn governor lever slightly to high speed side. (Fig.5)
4. Turn engine start switch to ON position. (Fig.6)
5. Hold recoil starter grip and pull it slightly until you feel light resistance. Pull it strongly there. Be careful not to pull it too hard however because it may come off. Do not release the grip from the pulled position but return it to starter case before releasing.(Fig.6)
6. If engine has started, while listening to explosion sound, slowly return the choke lever to OPERATION position. (Fig.7)

After started, be sure to run the engine at low speed for a few minutes.  
it must be done in cold climate in particular.  
Check for abnormal noise of gas leak in the meantime.





### Maneuvering the Trowel

1. With a secure foothold and a firm grasp on the handles slowly increase the engine speed until the desired blade speed is obtained.
2. To maneuver the trowel, gently lift up on or press down on the main trowel handle. To move the machine to the operator's left, **lift up** on the handle, to move machine to the right, **push down** on the handle.
3. The best method for finishing concrete is to slowly walk backwards with the trowel, guiding the trowel from side to side. This will cover all footprints on wet concrete.
4. Remember that if you let go of the trowel, just step away and let the trowel come to a complete stop before trying to recover the trowel.
5. Continue to practice maneuvering the trowel. Try to practice as if you were finishing a slab of concrete. Practice edging and covering a large area.

### **WARNING**

**NEVER** place your **feet or hands** inside the guard rings while starting or operating this equipment.

**ALWAYS** keep clear of **rotating or moving** parts while operating this equipment.

## 7. STOPPING

For stopping the engine with your work discontinued, return the throttle lever to low position to be in idle state for 2-3 minutes. After cooling down engine, stop the engine completely.

### Gasoline Engine

- a. Turn the engine switch to off (O) position to stop.
- b. After stopping the engine, align the fuel cock lever to off (O) position.

&. CAUTION

If the engine is stopped while it is still hot, it may hasten wear such as burn out of oil slick in cylinder.

## 8. TRANSPORTATION AND INSTALLATION

### Transportation Safety:

#### CAUTION

- + Shutdown the engine during transport.
- + Tighten fuel tank cap securely and close fuel cock to prevent fuel from spilling.
- + Drain fuel before transporting over long distance or on poor road.
- + Lock the machine securely so the machine does not move or topple over.
- + Operators for movement and installation shall hold a qualification certificate.
- + Please move the press with proper, safe and reliable tools.

### Installation Safety:

#### CAUTION

- + The field installation after unpacking shall follow requirements in this manual.
- + Installation conditions:
  - Ambient temperature: 5'C 4Q'C; no rapid changes causing dew.
  - Ambient humidity: 45% 65% (no dew)

9. TROUBLE SHOOTING

1. Engine

(1) Starting deficient

| SYMPTOM  | POSSIBLEM PROMBLEM                         | SOLUTION   |
|--|--|--|
| Fuel is available but spark plug will not ignite. (Power available at high tension cable).     | Ignition plug being bridge?                | Check ignition system.                                       |
|  | Carbon deposit at ignition?                | Clean ar replace ignition.                                   |
|  | Short circuit due ta defective insulators? | Replace insulators.  |
|  | Improper spark gap?                        | Set spark plug gap ta the correct gap.                       |
| Fuel is available but spark plug will not ignite, (Power NOT available at high tension cable.) | Short circuit at stop switch?              | Check stop switch circuit. Replace stop switch if defective. |
|  | Ignition coil defective?                   | Replace ignition coil.                                       |
| Fuel is available and spark plug ignites (compression normal).                                 | Muffler clogged with carbon deposits?      | Clean ar replace muffler.                                    |
|  | Fuel in use inadequate (water, dust)?      | Flush fuel system and replace with fresh fuel.               |
|  | Air Cleaner clogged?                       | Clean ar replace air cleaner.                                |
| Fuel is available and spark plug ignites (compression low).                                    | Defective cylinder head gasket?            | Tighten cylinder head bolts ar replace head gasket.          |
|  | Cylinder worn?                             | Replace cylinder.  |
|  | Spark plug loose?                          | Tighten spark plug.  |

(2) Operation deficient

| SYMPTOM  | POSSIBLEM PROMBLEM                                 | SOLUTION   |
|--|--|--|
| Not enough power available (compression normal, na misfiring). | Air cleaner clogged?                               |  |
|  | Air in fuel line?                                  | Bleed (remove air) from fuel line.               |
|  | Fuel level in carburetor float chamber improper?   | Adjust carburetor float                          |
|  | Carbon deposits in cylinder?                       | Clean ar replace cylinder                        |
| Not enough power available (compression normal, misfiring).    | Ignition coil defective?                           | Flush fuel system and replace with fresh fuel.   |
|  | Ignition plug often shorts?                        | Replace ignition wires, clean ignition.          |
|  | Fuel in use inadequate (water, dust)?              | Flush fuel system and replace with fresh fuel.   |
| Engine overheats.  | Excessive carbon deposition in combustion chamber? | Clean ar replace crankcase.                      |
|  | Exhaust ar muffler clogged with carbon.            | Clean ar replace muffler.                        |
|  | Spark plug heat value incorrect?                   | Replace spark plug with correct type spark plug. |

(3) Operation not satisfactory













| SYMPTOM                              | POSSIBLEM PROMBLEM                 | SOLUTION                          |
|--------------------------------------|------------------------------------|-----------------------------------|
| Rotational speed fluctuates.         | Governor adjustment improper?      | Adjust governor to correct lever. |
|                                      | governor spring defective?         | Clean or replace ignition.        |
|                                      | Fuel flow erratic?                 | Check fuel line.                  |
|                                      | Air taken in through suction line? | Check suction line.               |
| Recoil starter not working properly. | Dust in rotating part?             | Clean recoil starter assembly.    |
|                                      | Spiral spring failure?             | Replace spiral spring             |


2. Machine

| SYMPTOM  | POSSIBLEM PROMBLEM              | SOLUTION   |
|--|---------------------------------|--|
| Engine running rough or not at all.                                      | Safety stop switch malfunction? | Make sure that the Safety Stop Switch is <b>ON</b> or replace switch if necessary.   |
|  | Fuel?                           | Look at the fuel system. Make sure there is fuel being supplied to the engine. Check to ensure that the fuel filter is not clogged.  |
|  | Ignition?                       | Check to ensure that the ignition switch has power and is functioning correctly.   |
| Safety stop switch not functioning.                                      | Other problems?                 | Consult engine manufacturer's manual.  |
|  | Loose wire connections?         | Check wiring. Replace as necessary.  |
|  | Bad contacts?                   | Replace switch.  |
| If trowel "bounces, rolls concrete, or makes uneven swirls in concrete". | Blades?                         | Make certain blades are in good condition, not excessively worn, Finish blades should measure no less than 2" (50mm) from the blade bar to the trailing edge, combo blades should measure no less than 3.5 (89mm) . Trailing edge of blade should be straight and parallel to the blade bar. |
|  | Spider?                         | Check that ali blades are set at the same pitch angle as measured at the spider. A field adjustment tool is available far height adjustment of the trowel arms.  |
|  | Bent trowel arms?               | Check the spider assembly far bent trowel arms. If one of the arms is even slightly bent, replace it immediately.  |
|  | Trowel arm bushings?            | Check the trowel arm bushings far tightness. This can be done by moving the trowel arms up and down. If there is more than 1/8" (3.2mm) of travel at the tip of the arm, the bushings should be replaced. Ali bushings should be replaced at the same time.                                  |
|  | Thrust collar?                  | check the flatness of th thrust collar by rotating it one the spider. If it varies by more than 0.02" (0.5mm) replace the thrust collar.   |
|  | Thrust collar bushing?          | Check the thrust collar by rocking it on the spider. If it can tilt more than 3/32" (2.4mm) [as measured at the thrust collar O.O.] replace the bushing in the thrust collar.  |
|  | Thrust bearing worn?            | Check the thrust bearing to see that it is spinning free. Note: Thrust cap, replace if necessary.  |


|   |   |   |
|---|---|---|
| Machine has a perceptible rolling motion while running. | Main shaft?                               | The main output shaft of the gearbox assembly should be checked for straightness. The main shaft must run straight and cannot be more than 0.003" (0.08mm) out of round at the spider attachment point. |
|   | Yoke?                                     | Check to make sure that both fingers of the yoke press evenly on the wear cap. Replace yoke as necessary.   |
|   | Blade Pitch?                              | Check to ensure that each blade is adjusted or have the same pitch as all other blades. Adjust per maintenance section in manual.   |
| Sluggish response to engine speed change.               | Worn V-belts?                             | Replace V-belt.   |
|   | Dirty centrifugal clutch?                 | Disassemble and clean clutch.   |
|   | Defective or worn out centrifugal clutch? | Replace entire clutch.  |
|   | Worn bearings in gearbox?                 | Rotate input shaft by hand. If shaft rotates with difficulty, check the input and output shaft bearing. Replace as necessary.   |
|   | Worn or broken gears in gearbox?          | Verify that the gearbox shaft rotated when the input shaft is rotated. Replace both the worm and worm gear as a set.  |

## 10. SAFETY LABELS

|   |                        |   |                                 |   |                          |
|---|------------------------|---|---------------------------------|---|--------------------------|
|  | <b>DANGER<br/>FUEL</b> |  | <b>DANGER<br/>EXHAUST</b>       |  | <b>WARNING<br/>NOISE</b> |
|  |                        |  |                                 |  |                          |
| <b>Fire risk</b>  |                        | <b>Operate only in well-ventilated area</b>                                       |                                 | <b>Wear ear protection</b>  |                          |
|  | <b>CAUTION<br/>HOT</b> |  | <b>CAUTION<br/>MOVING PARTS</b> |  | <b>CAUTION<br/>READ</b>  |
|  |                        |  |                                 |  |                          |
| <b>Do not touch area of running engine</b>  |                        | <b>Do not touch parts in operation</b>  |                                 | <b>Read operator's manual carefully before use</b>                                |                          |



# PAST LIST(A)-ENGINE KIT & HANDLE KIT






**PART LIST -ENGINE KIT& HANDLE KIT**

| S/NO | PARTNO'          | DESCRIPTION           | QTY |
|------|------------------|-----------------------|-----|
| 1    | KM -P90 -01A     | HANDLE                | 1   |
| 2    | KM - P90 -02A    | HANDLE GRIB           | 2   |
| 3    | KM -P90 -0 3A    | THROTTLE LEVER        | 1   |
| 4    | KM -P90-04A      | COTTER PiN M6         | 1   |
| 5    | KM -P90 -0SA     | ADJUSTABLE HAND WHEEL | 1   |
| 6    | KM -P90 -0 6A    | BEARING               | 1   |
| 7    | KM-P90-07A       | BUSH                  | 1   |
| 8    | KM - P90-08A     | BOLT6X10T             | 1   |
| 9-1  | KM - P90-09-1A   | ADJUSTABLE AXIS       | 1   |
| 9-2  | KM-P90-09-2A     | ADJUSTABLE NUT        | 1   |
| 9-3  | KM -P90-09 -3A   | COTTER PiN M5         | 1   |
| 9-4  | KM -P90 -09 -4A  | COTTER PiN MS         | 1   |
| 9-5  | KM -P90-09 -5A   | ADJUSTABLE SHEATH     | 1   |
| 10   | KM - P90-010A    | BOLT6X10T             | 1   |
| 11   | KM - P90 -011A   | LOCK WEDGE            | 1   |
| 12   | KM -P90 -0 12A   | ENGINE                | 1   |
| 13   | KM -P90 -013A    | KEY                   | 1   |
| 14   | KM-P90-014A      | CLUTCH DRUM           | 1   |
| 15   | KM -P90 -015A    | BEARING               | 1   |
| 16   | KM -P90 -016A    | CIRCLIP               | 1   |
| 17   | KM-P90-017 A     | CLUTCH BOSS           | 1   |
| 18   | KM-P90-018A      | CLUTCH SPRING         | 2   |
| 19   | KM -P90 -019A    | CLUTCH SHOE           | 1   |
| 20   | KM-P90-020A      | CLUTCH GUIDE          | 1   |
| 21-1 | KM-P90-021-1A    | BOLT 8X20T            | 1   |
| 21-2 | KM - P90-021-2A  | SWM8                  | 1   |
| 21-3 | KM -P90 -021 -3A | WACHER M8             | 1   |
| 22   | KM -P90 -0 22A   | TOP ARMOR PLATE       | 1   |
| 23-1 | KM -P90 -023-1A  | BOLT 10X25 T          | 4   |
| 23-2 | KM-P90-023-2A    | WASHER MIO            | 4   |
| 23-3 | KM-P90-023-3A    | SWM10                 | 4   |
| 23-4 | KM - P90-023-4A  | NUTM10                | 4   |

ART LIST-ENGINE KIT&HANDLE KIT

| S/NO | PARTNO          | DESCRIPTION           | QTY |
|------|-----------------|-----------------------|-----|
| 24   | KM -P90 -24A    | UNDERSIDE ARMOR PLATE | 1   |
| 25-1 | KM -P90- 25-1A  | NUTM12                | 4   |
| 25-2 | KM -P90-2 5-2A  | SWM12                 | 4   |
| 25-3 | KM -P90 -25-3A  | WASHER M12            | 4   |
| 26   | KM-P90-26A      | WHEEL BRACKET         | 1   |
| 27   | KM - P90- 27A   | AERO WHEEL            | 1   |
| 28   | KM -P90 -28A    | SPINDLE               | 1   |
| 29   | KM -P90 -29A    | BLADE BASE , ENGiNE   | 1   |
| 30-1 | KM -P90 -30-1A  | WASHER M8             | 4   |
| 30-4 | KM -P90 -30-2A  | SWM8                  | 4   |
| 30-3 | KM -P90 -30-3A  | NUTM8                 | 4   |
| 31   | KM -P90 -31A    | BOLT8X17 T            | 4   |
| 32-1 | KM -P90 -32-1A  | NUT M10               | 4   |
| 33-1 | KM -P90-33-1A   | BOLT 10X20T           | 4   |
| 33-2 | KM-P90-33-2A    | SWM10                 | 1   |
| 34   | KM -P90 -34A    | CAP FOR SPEED REDUCER | 1   |
| 35   | KM-P90-35A      | REDUCER GEAR BOX      | 1   |
| 36-1 | KM -P90 -36-1A  | BOLT 10X25 T          | 1   |
| 36-2 | KM -P90 -36-2A  | SWM10                 | 2   |
| 36-3 | KM -P90 -36 -3A | WASHER M10            | 2   |
| 37   | KM-P90-37A      | KEY                   | 2   |
| 38   | KM -P90 -38A    | PULLEY                | 1   |
| 39   | KM-P90-39A      | SLIDE BOLT 8XIOT      | 1   |
| 40   | KM-P90-40A      | V-BELT                | 1   |
| 41   | KM -P90 -41A    | BELT COVER            | 1   |
| 42   | KM -P90 -42A    | FORK LEVER            | 1   |
| 43   | KM -P90-43A     | FIXATION PiN          | 1   |
| 44   | KM -P90 -44A    | SUSPEND AURIS         | 2   |

# PAST LIST(B)-GUARD RING & ARM BLADE KIT



**POWER TROWEL KM-P90**

**PART LIST -GUARD RiNG& ARM BLADE KIT**

| S/NO | PARTNO        | DESCRIPTION                    | QTY |
|------|---------------|--------------------------------|-----|
| 1    | KM-P90-01B    | GUARD RiNG                     | 1   |
| 2    | KM -P90-02B   | SPEED REDUCER                  | 1   |
| 3    | KM-P90-03B    | KEY 7X8X90                     | 1   |
| 4    | KM-P90-04B    | KEY 7X8X90                     | 1   |
| 5    | KM-P90-05B    | PRESURE CAP FOR THRUST BEARING | 1   |
| 6    | KM-P90-06B    | THRUST BEARING                 | 1   |
| 7    | KM-P90-07B    | PRESSURE CAP                   | 1   |
| 8    | KM-P90-08B    | BLADE BASE                     | 1   |
| 9    | KM-P90-09B    | ELBOW BLADE                    | 4   |
| 10-1 | KM-90-10-1B   | BOLT 10X35 T                   | 4   |
| 10-2 | KM-90-10-2B   | NUT M10                        | 4   |
| 11   | KM-P90-11B    | SLIDE BOLT 10X25 T             | 4   |
| 12   | KM-P90-12B    | ARM BLADE                      | 4   |
| 13-1 | KM-P90-13-1B  | BOLT8X45 T                     | 8   |
| 13-2 | KM-P90-13-2B  | SWM8                           | 8   |
| 13-3 | KM-P90-13-3B  | WASHER M8                      | 8   |
| 14   | KM-P90-14B    | TROWEL BLADE                   | 4   |
| 15-1 | KM-P90-15-1B  | BOLT 10X40T                    | 1   |
| 15-2 | KM-P90-15-2 B | SWM10                          | 1   |
| 16   | KM-P90-16B    | BOTTOM BLADE BASE CAP          | 1   |
| 17   | KM-P90-17B    | BLADE BASE COVER               | 1   |